

# Device Management & Deployments

## BRAdmin Professional 4

**brother**  
at your side

Manage your network-connected devices with BRAdmin Professional 4 and take advantage of real-time status updates, mass configuration, and enhanced security. Seamless integration with Microsoft Azure Storage platform enables IT administrators to remotely manage devices across various locations.



### Devices View

Customizable main screen for easy device assessment, installable on multiple PCs to share administration tasks.

### Smart Filters and Groups

Dynamic filters automatically group devices for simplified monitoring and management by model, serial number, contact, and more.

### Settings

Device configurations allow administrators to automate preferred device settings across multiple machines.

### Azure Integration

Device configurations allow administrators to automate preferred device settings across multiple machines.

## Configure specific device settings for policy compliance with Master Settings and Autoconfiguration:

**Master Settings** are preferred settings that administrators can apply to devices:

- Updating device firmware automatically.
- Sending settings files to devices.

**Frequency:** Run on daily or weekly schedule.

**Autoconfiguration** ensures that devices are consistently set to the customer's standard settings.

- Automatic configuration for devices that don't meet a set criteria.
- Applying specified settings via BRAdmin Professional 4 once the device is discovered.

**Frequency:** Monitor devices daily, weekly, monthly, or in a specified time period, e.g. every "X" hours.

| Features                                                       | Master Settings | Autoconfiguration |
|----------------------------------------------------------------|-----------------|-------------------|
| Change device password                                         | ✓               | ✓                 |
| Send configuration files                                       | ✓               | ✓                 |
| Firmware auto-update                                           | ✓               | ✓                 |
| Configure Value Services                                       | ✓               | ✓                 |
| Activate Value Services                                        |                 | ✓                 |
| Set trigger to send settings file <sup>1</sup>                 |                 | ✓                 |
| Apply various settings <sup>2</sup>                            |                 | ✓                 |
| Monitor target devices                                         |                 | ✓                 |
| Set device password to company policy without current password |                 | ✓                 |

<sup>1</sup> Uses trigger when device discovery is run.

<sup>2</sup> Settings can be applied using smart filter, groups, profiles, serial number, model name, node name, MAC address, and IP address.

### DID YOU KNOW?

Choose **Autoconfiguration** to detect new devices on the network and automatically push the desired security configuration.

### Configure the following using BRAdmin Professional 4:

#### Run on your local network



Manage and monitor devices on your local network.

#### Run on Microsoft Azure



Manage devices on multiple isolated networks and compatible Brother devices via cloud. No local software needed.

#### Monitor USB connected devices



Easily manage and monitor devices connected via USB on local network.

### Take control with BRAdmin Professional 4 advanced features:

#### Microsoft Azure Profile View

Enables IT professionals to remotely manage devices in multiple isolated locations.

- View multiple profiles from a single dashboard.
- Store device data in Azure cloud storage.
- Offers robust security for secure access and remote management.

#### Devices View

Offers the capability to instantly monitor page counts and supply levels.

- Easy reference user interface provides access to common tasks.
- Identify device status with color-coded indicators.
- Keep track of toner and ink volume levels.

#### Tasks View

Allows IT administrators to quickly identify any errors for faster issue resolution.

- Monitor the status of scheduled and one-off tasks.
- Quickly identify issues or failures.
- View active tasks and logs for Notification Alerts, Master Settings, and Autoconfiguration.

| Device status    | Model name                  | Toner/ink volume | Location   | Contact  | Total page count | Color page count | Monochrome page count | Total scanned pages | Firmware version |
|------------------|-----------------------------|------------------|------------|----------|------------------|------------------|-----------------------|---------------------|------------------|
| Toner Low (C)    | Brother MFC-L9570CDW series |                  | BMGLAB     | FSE_Team | 7966             | 6126             | 1840                  | 425                 | 12310171922      |
| Sleep            | Brother MFC-L6750DW series  |                  | BMGLAB     | FSE_Team | 2368             |                  |                       | 711                 | ZZ2310310247     |
| Ready            | Brother MFC-J5955DW         |                  | BMGLAB     | FSE_Team | 2645             | 2604             | 41                    | 30                  | 1.20             |
| Ready            | Brother HL-L9310CDW series  |                  | BMGLAB     | FSE_Team | 966              | 849              | 117                   |                     | b.60             |
| Ready            | Brother MFC-L5700DW series  |                  | BMGLAB     | FSE_Team | 108              |                  |                       | 716                 | ZZ2310310247     |
| Ready            | Brother MFC-L9670CDN series |                  | BMGLAB     | FSE_Team | 156247           | 85188            | 71059                 | 297                 | 1.21             |
| Sleep            | Brother HL-L6400DW series   |                  | BMGLAB     | FSE_Team | 4323             |                  |                       |                     | 1.95             |
| Paper Low Tray 2 | Brother MFC-EX915DW series  |                  |            |          | 268              |                  |                       | 84                  | 1.15             |
| No Paper Tray 1  | Brother HL-L6415DW series   |                  | BMGLAB_PRE | FSE_Team | 74               |                  |                       |                     | 0.67             |